


Rotary actuator fail-safe for zone valves

- Nominal voltage AC/DC 24 V
- Control Open/close
- Snap-assembly of the actuator
- Flow setting variable
- Deenergised closed (NC)


Technical data

| | | |
|------------------------|--|---|
| Electrical data | Nominal voltage | AC/DC 24 V |
| | Nominal voltage frequency | 50/60 Hz |
| | Nominal voltage range | AC 19.2...28.8 V / DC 21.6...28.8 V |
| | Power consumption in operation | 2.5 W |
| | Power consumption in rest position | 0.5 W |
| | Power consumption for wire sizing | 5 VA |
| | Connection supply / control | Terminals 2.5 mm ² (cable ø6...8 mm, 2-wire) |
| | Parallel operation | Yes (note the performance data) |
| Functional data | Torque motor | 1 Nm |
| | Direction of motion fail-safe | fix deenergised closed (end stop NC = 0%) |
| | Manual override | with actuator (clicked out) |
| | Running time motor | 75 s / 90° |
| | Running time fail-safe | 60 s / 90° |
| | Sound power level, motor | 35 dB(A) |
| | Sound power level, fail-safe | 35 dB(A) |
| | Position indication | Mechanical |
| Flow setting | see product features | |
| Safety data | Protection class IEC/EN | III, Safety Extra-Low Voltage (SELV) |
| | Degree of protection IEC/EN | IP40 |
| | EMC | CE according to 2014/30/EU |
| | Certification IEC/EN | IEC/EN 60730-1 and IEC/EN 60730-2-14 |
| | Type of action | Type 1.AA |
| | Rated impulse voltage supply / control | 0.8 kV |
| | Pollution degree | 2 |
| | Ambient humidity | Max. 95% RH, non-condensing |
| | Ambient temperature | 5...40°C [41...104°F] |
| | Storage temperature | -40...80°C [-40...176°F] |
| | Servicing | maintenance-free |
| | Weight | Weight |
| Terms | Abbreviations | POP = Power off position / fail-safe position PF = Power fail delay time / bridging time |

Safety notes




- This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.
- Outdoor application: only possible in case that no (sea) water, snow, ice, insolation or aggressive gases interfere directly with the device and that it is ensured that the ambient conditions remain within the thresholds according to the data sheet at any time.
- Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.

Product features

Mode of operation The actuator moves the valve to the desired operating position at the same time as the integrated capacitors are loaded.
 Interrupting the supply voltage causes the valve to be moved to the fail-safe position by means of stored electrical energy, taking into account the bridging time (PF) of 1 s set at the factory.

Pre-charging time (start up) The capacitor actuators require a pre-charging time. This time is used for charging the capacitors up to a usable voltage level. This ensures that, in the event of a power failure, the actuator can move at any time from its current position into the fail-safe position. The duration of the pre-charging time depends mainly on how long the power was interrupted.

Typical pre-charging time



[d] = Power failure in days
 [s] = Pre-charging time in seconds

| | [d] | | | | |
|-----|-----|---|----|----|----|
| | 0 | 3 | 6 | 9 | 12 |
| [s] | 6 | 8 | 10 | 12 | 14 |

Delivery condition (capacitors) The actuator is completely discharged after delivery from the factory, which is why the actuator requires approximately 25 s pre-charging time before initial commissioning in order to bring the capacitors up to the required voltage level.

Simple direct mounting Tool-free snap assembly.
 The actuator can be plugged on the valve by hand (Caution! Just vertical movements). Pins must match the holes on the flange.
 The mounting orientation in relation to the valve can be selected in 180° increments. (Possible two times)

Manual override Click out the actuator and rotate the valve spindle with the help of the actuator.


Adjustable angle of rotation The angle of rotation of the actuator can be changed by clip in 2.5° increments. This is used to set the maximum flow rate of the valve.

High functional reliability The actuator is overload protected, requires no limit switches and automatically stops when the end stop is reached.

Flow setting Adjustable kv-values (C2..Q-., C4..Q-.) / Vmax-values (C2..QP(T)-.) are given in the respective zone valve data sheets.

2-way valve: Remove end stop clip and place at desired position.

3-way valve: Remove end stop clip (change-over application).



Accessories

| Mechanical accessories | Description | Type |
|------------------------|----------------------------------|--------|
| | Spindle extension CQ | ZCQ-E |
| | End stop clip, Multipack 5 pcs. | ZCQ-C |
| | End stop clip, Multipack 20 pcs. | Z-ESCM |

Electrical installation



Supply from isolating transformer.

Parallel connection of other actuators possible. Observe the performance data.


Wiring diagrams

AC/DC 24 V, open/close




| 1 | 2 | |
|---|---|---------------|
| | | |
| | | A - AB = 0% |
| | | A - AB = 100% |

Operating controls and indicators



① Push-button: no function

Dimensions



Further documentation

- The complete product range for water applications
- Data sheet for zone valves
- Installation instructions for zone valves and actuators
- General notes for project planning