

Rotary actuator with fail-safe for ball valves and butterfly valves

- Torque motor 20 Nm
- Nominal voltage AC 24...240 V / DC 24...125 V
- Control Open/close
- Deenergised closed (NC)
- with 2 integrated auxiliary switches



Technical data

	lectri	!		
-	ectr	ra	na	па

Nominal voltage	AC 24240 V / DC 24125 V		
Nominal voltage frequency	50/60 Hz		
Nominal voltage range	AC 19.2264 V / DC 21.6137.5 V		
Power consumption in operation	7 W		
Power consumption in rest position	3.5 W		
Power consumption for wire sizing	18 VA		
Auxiliary switch	2 x SPDT, 1 x 10% / 1 x 11100%		
Switching capacity auxiliary switch	1 mA3 A (0.5 A inductive), DC 5 VAC 250 V		
Connection supply / control	Cable 1 m, 2 x 0.75 mm ²		
Connection auxiliary switch	Cable 1 m, 6 x 0.75 mm ²		
Parallel operation	Yes (note the performance data)		

Functional data

Torque motor	20 Nm
Torque fail-safe	20 Nm
Direction of motion fail-safe	Deenergised NC, valve closed (A – AB = 0%)
Manual override	by means of hand crank and locking switch
Running time motor	75 s / 90°
Running time fail-safe	<20 s @ -2050°C / <60 s @ -30°C
Sound power level, motor	45 dB(A)
Position indication	Mechanical
Service life	Min. 60'000 fail-safe positions

Safety data

Protection class IEC/EN	II, reinforced insulation		
Protection class UL	II, reinforced insulation		
Protection class auxiliary switch IEC/EN	II, reinforced insulation		
Degree of protection IEC/EN	IP54		
Degree of protection NEMA/UL	NEMA 2		
Enclosure	UL Enclosure Type 2		
EMC	CE according to 2014/30/EU		
Low voltage directive	CE according to 2014/35/EU		
Certification IEC/EN	IEC/EN 60730-1 and IEC/EN 60730-2-14		
UL Approval	cULus according to UL60730-1A, UL60730-2-14		
	and CAN/CSA E60730-1		
	The UL marking on the actuator depends on		
	the production site, the device is UL-compliant		
	in any case		
Type of action	Type 1.AA.B		
Rated impulse voltage supply / control	4 kV		
Rated impulse voltage auxiliary switch	2.5 kV		
Pollution degree	3		
Ambient humidity	Max. 95% RH, non-condensing		
Ambient temperature	-3050°C [-22122°F]		



	recrimed data street		51(17(52 5
Safety data	Storage temperature	-4080°C [-40176°F]	
	Servicing	maintenance-free	
Mechanical data	Connection flange	F05	
Weight	Weight	2.4 kg	

Safety notes



- This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.
- Outdoor application: only possible in case that no (sea) water, snow, ice, insolation or aggressive gases interfere directly with the device and that it is ensured that the ambient conditions remain within the thresholds according to the data sheet at any time.
- · Caution: Power supply voltage!

Technical data sheet

- Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- Cables must not be removed from the device.
- The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.
- The two switches integrated in the actuator are to be operated either on power supply voltage
 or at safety extra-low voltage. The combination power supply voltage/safety extra-low voltage
 is not permitted.

Product features

Mode of operation The actuator is equipped with a universal power supply module that can utilise supply voltages

of AC 24...240 V and DC 24...125V.

The actuator moves the valve to the operating position at the same time as tensioning the return spring. The valve is turned back to the fail-safe position by spring force when the supply voltage is interrupted.

Simple direct mounting Simple direct mounting on the rotary valve or butterfly valve with mounting flange. The

mounting orientation in relation to the fitting can be selected in 90° steps.

Manual override By using the hand crank the valve can be operated manually and engaged with the locking

switch at any position. Unlocking is carried out manually or automatically by applying the

operating voltage.

Adjustable angle of rotation Adjustable angle of rotation with mechanical end stops.

High functional reliability The actuator is overload protected, requires no limit switches and automatically stops when the

end stop is reached.

Flexible signalling The actuator has one auxiliary switch with a fixed setting and one adjustable auxiliary switch.

They permit a 10% or 11...100% angle of rotation to be signaled.

Electrical installation



Caution: Power supply voltage!

Parallel connection of other actuators possible. Observe the performance data.



Wire colours:

1 = blue

2 = brown

S1 = violet

S2 = red

S3 = white

S4 = orange


S5 = pink

S6 = grey


Wiring diagrams

AC 24...240 V / DC 24...125 V, open/ Auxiliary switch





Operating controls and indicators



Auxiliary switch settings

<u>^</u>

Note: Perform settings on the actuator only in deenergised state.

For the auxiliary switch position settings, carry out points 1 to 2 successively.

Manual override

Turn the hand crank until the desired switching position is set.

Shaft clamp

Edge line A displays the desired switching position of the actuator on the scale.

3 Fasten the locking device

Turn the locking switch to the "Locked padlock" symbol.

4 Auxiliary switch

Turn rotary knob until the notch points to the arrow symbol.

5 Unlock the locking device

Turn the locking switch to the "Unlocked padlock" symbol or unlock with the hand crank.

6 Cable


Connect continuity tester to S4 + S5 or to S4 + S6.

7 Manual override

Turn the hand crank until the desired switching position is set and check whether the continuity tester shows the switching point.



Dimensions



Further documentation

- The complete product range for water applications
- Data sheets for rotary valves and butterfly valves
- Installation instructions for actuators and/or rotary valves and butterfly valves
- General notes for project planning