

Differential pressure sensor Air dual

Differential pressure transmitter with two independent measuring systems. With 8 selectable ranges each and Modbus functionality. For monitoring over-, under- or the differential pressure of air and other nonflammable and non-aggressive gases. Typical application in HVAC systems for monitoring air filters, fans V-belts as well as the use in pressure differential systems. IP65 / NEMA 4X rated enclosure.





### **Type Overview**

Туре	Measuring range pressure [Pa]	Comr	nunication	Output signal active pressure	Output signal active volumetric flow	Burst pressure	Display type
22ADP-154F	-1002500	Мос	lbus RTU	05 V, 010 V	05 V, 010 V	40 kPa	LCD
echnical data							
	Electrica	l data	Nominal v	voltage	AC/DC	24 V	
				voltage range	AC 19.	29 V / DC 1535 V	
			Power cor	nsumption AC	4.3 VA		
			Power cor	nsumption DC	2.3 W		
			Electrical	connection	Plugga 2.5 mr	able spring loaded te n²	rminal block max
			Cable ent	ŷ	Cable	gland with strain reli	ef 2x ø6 mm
	Data bus communication		Communication		Modbus RTU		
			Number o	of nodes	Modbu	us see interface desc	ription
	Functional data		Sensor Technology		Piezo measuring element		
			Applicatio	n	Air		
			Multirang	e	8 mea	suring ranges selecta	able
			Voltage o	utput	2 x 0	5 V, 010 V, min. res	istance 10 kΩ
			Output sig	gnal active note	Outpu	t 05/10 V selectable	e with switch
			Display			9x35 mm	
						acklight	
						red values volumetri	ic flow: m³/h, cfm
						netrisable) red values pressure:	Da inch WC
						netrisable)	
			Response	time		able 0.8 s or 4.0 s	
	Measuring	g data	Measured	values		ential pressure etric flow	
			Measurin	a fluid		d non-aggressive gas	:es



**Technical data sheet** 

22ADP-154F

data						
Measuring data	Measuring range pressure settings	Setting	Range [Pa]	Range [inch WC]	Factory setting	
		S0	02500	010	<b>~</b>	
		S1	02000	08		
		S2	01500	06		
		S3	01000	04		
		S4	0500	02		
		S5	0250 0100	01		
		S6 S7	-100100	00.4 -0.40.4		
		-				
	Measuring range volumetric flow	•	Adjustable via Modbus			
		Default setting: 0750'000 m³/h Selectable units: m³/h, m³/s, cfm				
		Deviation compared to the reference device				
	Accuracy pressure		ng range ≤50		vice	
			ng range >50			
	Long-term stability			Output) / 4 yr.		
Materials	Cable gland	PA6, blac				
	Housing	Cover: PC, orange				
			PC, orange			
		UV resist	R70, black			
		UVTESIS	.dTL			
Safety data	Protection class IEC/EN	III, Safet	y Extra-Low \	/oltage (SELV)		
	Power source UL	Class 2 S	upply			
	Degree of protection IEC/EN	IP65				
	Degree of protection NEMA/UL	NEMA 4>	(			
	Enclosure	UL Enclo	sure Type 4X			
	EU Conformity	CE Marki	ing			
	Certification IEC/EN	IEC/EN 6	0730-1 and I	EC/EN 60730-2-6		
	Quality Standard	ISO 9001				
	UL Approval	cULus ac E60730-1		0-1A/-2-6, CAN/CSA	A	
	Type of action	Type 1	•			
	Rated impulse voltage supply	0.8 kV				
	Installation method		dently moun	ted control		
	Pollution degree	3	a sing moun			
	Ambient humidity		% RH, non-co	ndensing		
	Ambient temperature		C [15122°F]			
	Fluid temperature		C [15122°F]			
			· · · · · · · · · · · · · · · · · · ·	-		

### Safety notes



This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application. Unauthorised modifications are prohibited. The product must not be used in relation with any equipment that in case of a failure may threaten humans, animals or assets.

Ensure all power is disconnected before installing. Do not connect to live/operating equipment. Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied with during installation.

The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.



Remarks					
Manual zero-point calibration	<ul> <li>In normal operation zero-point calibration should be executed every 12 months. Attention! For executing zero-point calibration, the power supply must be connected one hour before.</li> <li>Release both tube connectors from the pressure ports + and -</li> <li>Press the button "Manual zero-point calibration" until the LED lights permanently</li> <li>Wait until the LED flashes again and reinstall the tube connectors to the pressure ports (not and -)</li> </ul>				
Indicators and Operation					
Indicators	Depending on the device and the number of measured values, the display automatically scales Parameters, such as the fading in/out of measured values, brightness and traffic light function are changed via the app or bus system. During the boot process, the software and hardware versions are displayed.				
0 2 3 4	Fault / sensor failure				
	2 Service / visual inspection due				
❺→{▲★₩奈}	<ul> <li>3 TLF (traffic light function) active (thresholds for display colour changes)</li> </ul>				
6 dP *	4 Radio active (not available)				
	5 Status bar				
	6 Measured value (* appears when TLF function is activated for this value)				
	7 Unit of measure				
	8 Measured value				
Parts included					
	Description	Туре			
	Mounting plate L housing	A-22D-A10			
	Duct connector kit, PVC tube 2 m, 2 connection elements (Plastic) for 22ADP	A-22AP-A08			
	Cable Gland with strain relief ø68 mm Dowels Screws				
Accessories					
Ontional accessories	Description	Tyme			

Optional accessories	Description	Туре
	Pitot tube, Metal, L 40 mm, Tube connection 5 mm	A-22AP-A02
	Pitot tube, Metal, L 100 mm, Tube connection 5 mm	A-22AP-A04
	Connection adapter flex conduit, M20x1.5, for cable gland 1 x 6 mm, Multipack 10 pcs.	A-22G-A01.1
	Connection adapter flex conduit, M20, for cable gland 2x 6 mm, Multipack 10 pcs.	A-22G-A02.1
	Airflow volume probe 100 mm for round duct, min. 2 m/s	EXT-AC-R100
	Airflow volume probe 125 mm for round duct, min. 2 m/s	EXT-AC-R125
	Airflow volume probe 160 mm for round duct, min. 2 m/s	EXT-AC-R160
	Airflow volume probe 200 mm for round duct, min. 2 m/s	EXT-AC-R200
	Airflow volume probe 250 mm for round duct, min. 2 m/s	EXT-AC-R250
	Airflow volume probe 315 mm for round duct, min. 2 m/s	EXT-AC-R315
	Airflow volume probe 400 mm for round duct, min. 2 m/s	EXT-AC-R400
	Airflow volume probe 500 mm for round duct, min. 2 m/s	EXT-AC-R500



Servi

essories			
	Description	Туре	
	Airflow volume probe 630 mm for round duct, min. 2 m/s	EXT-AC-R630	
	Airflow volume probe 200 mm for rectangular duct, min. 2 m/s	EXT-AC-L200	
	Airflow volume probe 250 mm for rectangular duct, min. 2 m/s	EXT-AC-L250	
	Airflow volume probe 300 mm for rectangular duct, min. 2 m/s	EXT-AC-L300	
	Airflow volume probe 400 mm for rectangular duct, min. 2 m/s	EXT-AC-L400	
	Airflow volume probe 500 mm for rectangular duct, min. 2 m/s	EXT-AC-L500	
	Airflow volume probe 600 mm for rectangular duct, min. 2 m/s Airflow volume probe 700 mm for rectangular duct, min. 2 m/s	EXT-AC-L600 EXT-AC-L700	
Tools	Description	Туре	
10013	Belimo Duct Sensor Assistant App	Belimo Duct	
	Bellino Duct Selisor Assistant App	Sensor Assistant	
		App	
	Bluetooth dongle for Belimo Duct Sensor Assistant App	A-22G-A05	
	* Bluetooth dongle A-22G-A05		
	Certified and available in North America, European Union, EFTA State	s and LIK	
vice			
Tools connection	This sensor can be operated and parametrised using the Belimo Duct	Sensor Assistant App.	
	When using the Belimo Duct Sensor Assistant App, the bluetooth don communication between the app and the Belimo sensor.	gle is required to enable	
	For the standard operation and parametrisation of the sensor the blu Belimo Duct Sensor Assistant App are not needed. The sensor will arr factory default settings shown above.	-	
	Requirement:		
	- Bluetooth dongle (Belimo Part No: A-22G-A05)		
	- Bluetooth-capable smartphone		
	- Belimo Duct Sensor Assistant App (Google Play & Apple App Store)		
	Procedure:		
	- Plug the Bluetooth dongle into the sensor via the Micro-USB connec	tor or by means of the	
	interface PCB	tor or by means or the	
	- Connect Bluetooth-capable smartphone with Bluetooth dongle		
	- Select parametrisation in the Belimo Duct Sensor Assistant App		

(((·)))

BELIMO

BELIMO




#### Wiring diagram



**s** Supply from isolating transformer.

The wiring of Modbus RTU (RS-485) is to be carried out in accordance with applicable regulations (www.modbus.org). The device has switchable resistors for bus termination. Modbus-GND: Supply and communication are not galvanically isolated. Connect earth signal of the devices with one another.



Detailed documentation

The separate document Sensor Modbus-Register informs about Modbus register, addressing, parity and bus termination (DIP1: address, DIP2: baud rate, parity, bus termination) In addition to the information on the bus, the following analog outputs are available:

AOU1: differential pressure 1


AOU2: differential pressure 2

If required, the outputs AOU1 and AOU2 can be changed to volumetric flow via bus system. The volumetric flow is calculated from the differential pressure, the k-factor and the height. Factory setting for the k-factor is 1.00 and for the height 330 metres above sea level. The values of the k-factor and the height can be changed via bus system.




# Wiring diagram

Wiring RS-485 Modbus RTU



#### Dimensions



www.belimo.com

22ADP-154F

Туре



# Further documentation

- Modbus Interface description
- Installation instructions