

Outdoor sensor with weather and radiated heat shield Humidity / Temperature

Active humidity and temperature sensor (4...20 mA) for outside applications. The radiation shield protects the outside sensors from rain and radiated heat. With the curved shape and colour of the plates, airflow is able to move across the sensors to keep radiated temperatures from rooftops and surrounding surfaces from affecting humidity readings.

Technical data sheet

22UTH-130X



Type Overview

•

	Туре	Output signal active temperature	Output signal active h	umidity
	22UTH-130X	420 mA	420 mA	
Technical data				
Electrical data	Nominal voltage	DC 24 V		
	Nominal voltage range	DC 13.526.4 V		
	Power consumption DC	1 W		
	Electrical connection	Pluggable sprin 2.5 mm²	g loaded terminal block	: max.
	Cable entry	Cable gland wit	h strain relief ø68 mm	
Functional data	Sensor Technology		Polymer capacitive sensor with stainless steel wire mesh filter	
	Application	Air		
	Multirange	4 measuring rai	nges selectable	
	Current output	2x 420 mA, m	ax. resistance 500 Ω	
Measuring data	Measured values	Relative humidi Absolute humid Dew point Enthalpies Temperature		
	Measuring range humidity	0100% RH nor	n-condensing	
	Measuring range temperate		reondensing	
		Active sensor: ra Attention: max. restricted by ma data)		
				setting
			4060 -40160 050 40140	
			1535 40140	
			2080 0200	\checkmark
	Measuring range absolute l		adjustable at the transducer: 050 g/m³ (default setting)	
	Measuring range enthalpy	085 kJ/kg		
	Measuring range dew point	2	adjustable at the transducer: 050°C (default setting)	
	Accuracy humidity	±2% between 0.	80% RH @ 25°C	
	Accuracy temperature activ	e ±0.3°C @ 25°C [±0.54°F @ 77°F]	



Technical data sheet

M			
Measuring data	Long-term stability	±0.3% RH p.a. @ 21°C @ 50% RH	
		±0.05°C p.a. @ 21°C [±0.09°F p.a. @ 70°F]	
	Time constant $ au$ (63%) in the room	Relative humidity: typical 16 s @ 0 m/s	
		Temperature: typical 351 s @ 0 m/s	
Materials	Cable gland	PA6, white	
	Housing	Cover: PC, white	
		Bottom: PC, white	
		Seal: NBR70, black	
		UV resistant	
Safety data	Protection class IEC/EN	III, Safety Extra-Low Voltage (SELV)	
	Power source UL	Class 2 Supply	
	Degree of protection IEC/EN	IP65	
	Degree of protection NEMA/UL	NEMA 4X	
	Enclosure	UL Enclosure Type 4X	
	EU Conformity	CE Marking	
	Certification IEC/EN	IEC/EN 60730-1	
	Quality Standard	ISO 9001	
	Type of action	Туре 1	
	Rated impulse voltage supply	0.8 kV	
	Installation method	Independently mounted control	
	Pollution degree	3	
	Ambient humidity	Short-term condensation permitted	
	Ambient temperature	-3550°C [-30122°F]	
	Fluid humidity	Short-term condensation permitted	
	Fluid temperature	-3550°C [-30122°F]	
	Operating condition airflow	max. 12 m/s	

Safety notes



This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application. Unauthorised modifications are prohibited. The product must not be used in relation with any equipment that in case of a failure may threaten humans, animals or assets.

Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.

The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.

Remarks

General remarks concerning sensors

When using lengthy connection wires (depending on the cross section used) the measuring result might be falsified due to a voltage drop at the common GND-wire (caused by the voltage current and the line resistance). In this case, 2 GND-wires must be wired to the sensor - one for supply voltage and one for the measuring current.


Sensing devices with a transducer should always be operated in the middle of the measuring range to avoid deviations at the measuring end points. The ambient temperature of transducer electronics should be kept constant. The transducers must be operated at a constant supply voltage (± 0.2 V). When switching the supply voltage on/off, onsite power surges must be avoided.




Technical data sheet

Optional accessories	Description	Туре	
Accessories			
	Dowels Screws		
Parts included			
	Long term operation outside the recommended conditions (560°C a in a temporary offset. After returning into the recommended range, t		
Application notice for humidity sensors	ensors The humidity sensor is extremely sensitive. Touching the sensor element or exposing it to aggressive substances like chlorine, ozone, ammonia, hydrogen peroxide or ethanol (i.e. as a cleaning agent) may affect the measurement accuracy.		
	- For bus sensors via bus interface with a corresponding software var	iable	
	- For sensors with a trimming potentiometer on the sensor board		
	- For sensors with NFC or dongle with the corresponding Belimo app		
	If a readjustment directly at the active sensor should be necessary du can be done with the following adjustment methods.	iring later operation, this	
	In case of a fixed operating voltage (±0.2 V), this is normally done by constant offset value. As Belimo transducers work with a variable ope of production engineering only one operating voltage can be taken in Transducers 010 V / 420 mA have a standard setting at an operatimeans that at this voltage, the expected measuring error of the outp For other operating voltages, the offset error will be increased by a c sensor electronics.	erating voltage, for reasons nto consideration. ng voltage of DC 24 V. This ut signal will be the least.	
Build-up of self-heating by electrical dissipative power			







① Status LED
RH Relative humidity
absH Absolute humidity
EntH Enthalpy
TPkt/Dew Dew point
(Measurement value available on Output AOI1)

Connectors ST+ / ST- are only used for sensor types which additionally have a passive resistance sensor element for temperature measurement.


Correct temperature values are only available, when the humidity output AOI1 and both inputs UB + are connected.

The adjustment of the measuring ranges is made by changing the bonding jumpers. The output value in the new measuring range is available after 2 seconds.

•			
Setting	Range [°C]	Range [°F]	Factory setting
S0	-4060	-40160	
S1	050	40140	
S2	-1535	0100	
S3	-2080	0200	\checkmark







Туре	Weight
22UTH-130X	0.54 kg

Further documentation

• Installation instructions